



# IADC WellCAP Well Control Worksheet

## Surface Stack - Wait and Weight Method

Well Name: \_\_\_\_\_ Completed By: \_\_\_\_\_ Date: \_\_\_\_ / \_\_\_\_ / \_\_\_\_

### PRE-RECORDED INFORMATION

**TRUE PUMP OUTPUT:** \_\_\_\_\_ **X** \_\_\_\_\_ = \_\_\_\_\_  
Bbbls/Stk @ 100%      % Efficiency      TPO (Bbbls/Stk)

Surface Line: \_\_\_\_\_ (Bbbls) ÷ \_\_\_\_\_ = \_\_\_\_\_  
Surface Line Capacity      True Pump Output (Bbbls/Stk)      Strokes to Pump

**DRILL STRING CAPACITY:**

Drill #1: \_\_\_\_\_ **X** \_\_\_\_\_ = \_\_\_\_\_ Bbbls  
Pipe      Size (in.)      Weight (lb/ft)      Bbbls/ft      Length (ft)      DP

Drill #2: \_\_\_\_\_ **X** \_\_\_\_\_ = \_\_\_\_\_ Bbbls  
Pipe      Size (in.)      Weight (lb/ft)      Bbbls/ft      Length (ft)      DP

HWDP: \_\_\_\_\_ **X** \_\_\_\_\_ = \_\_\_\_\_ Bbbls  
Size (in.)      Weight (lb/ft)      Bbbls/ft      Length (ft)      HWDP

Drill #1: \_\_\_\_\_ **X** \_\_\_\_\_ = \_\_\_\_\_ Bbbls  
Collars      Size (in.)      Weight (lb/ft)      Bbbls/ft      Length (ft)      DC

Drill #2: \_\_\_\_\_ **X** \_\_\_\_\_ = \_\_\_\_\_ Bbbls  
Collars      Size (in.)      Weight (lb/ft)      Bbbls/ft      Length (ft)      DC

\_\_\_\_\_ / \_\_\_\_\_ = \_\_\_\_\_  
Total Drill String Capacity (Bbbls)

**STROKES FROM SURFACE TO BIT:**

\_\_\_\_\_ ÷ \_\_\_\_\_ = \_\_\_\_\_  
Total Drill String Capacity (Bbbls)      True Pump Output (Bbbls/Stk)      Strokes, Surface to Bit

**ANNULAR CAPACITY:**

Between CSG and DP: \_\_\_\_\_ Bbbls/ft **X** \_\_\_\_\_ ft = \_\_\_\_\_ Bbbls

Between Liner #1 and DP: \_\_\_\_\_ Bbbls/ft **X** \_\_\_\_\_ ft = \_\_\_\_\_ Bbbls

Between Liner #2 and DP: \_\_\_\_\_ Bbbls/ft **X** \_\_\_\_\_ ft = \_\_\_\_\_ Bbbls

Between OH and DP/HWDP: \_\_\_\_\_ Bbbls/ft **X** \_\_\_\_\_ ft = \_\_\_\_\_ Bbbls

Between OH and DC: \_\_\_\_\_ Bbbls/ft **X** \_\_\_\_\_ ft = \_\_\_\_\_ Bbbls

Between OH and DC: \_\_\_\_\_ Bbbls/ft **X** \_\_\_\_\_ ft = \_\_\_\_\_ Bbbls

**STROKES FROM BIT TO SHOE:**

\_\_\_\_\_ ÷ \_\_\_\_\_ = \_\_\_\_\_  
Open Hole Annular Vol. (Bbbls)      True Pump Output (Bbbls/Stk)      Strokes, Bit to Shoe

**STROKES FROM BIT TO SURFACE:**

\_\_\_\_\_ ÷ \_\_\_\_\_ = \_\_\_\_\_  
Total Annular Volume (Bbbls)      True Pump Output (Bbbls/Stk)      Strokes, Bit to Surface

**TOTAL STROKES FROM SURFACE TO SURFACE:**

\_\_\_\_\_ + \_\_\_\_\_ = \_\_\_\_\_  
Strokes, Surface to Bit      Strokes, Bit to Surface      Strokes, Surface to Surface

**MAXIMUM ALLOWABLE MUD DENSITY (ppg)**

( \_\_\_\_\_ ÷ 0.052 ÷ \_\_\_\_\_ ) + \_\_\_\_\_ = \_\_\_\_\_ ppg      **MAX. ALLOWABLE MUD DENSITY**

**MAXIMUM ALLOWABLE ANNULAR SURFACE PRESSURE (MAASP) (psi)**

( \_\_\_\_\_ - \_\_\_\_\_ ) **X** 0.052 **X** \_\_\_\_\_ = \_\_\_\_\_ psi      **MAX. ALLOWABLE ANNULAR SURFACE PRESSURE**

### CURRENT WELL DATA

**PRESENT MUD WEIGHT:** \_\_\_\_\_ ppg

**SLOW CIRCULATION RATE (SCR):** SCR taken @ \_\_\_\_\_ (ft)

	Stks/min	Pressure (psi)	Bbl/min	Pressure (psi)
Pump #1				
Pump #2				
Pump #3				

**CASING DATA:**

CASING \_\_\_\_\_ size, \_\_\_\_\_ ID, \_\_\_\_\_ weight

SHOE DEPTH @ MD / TVD \_\_\_\_\_ / \_\_\_\_\_ ft

**SHOE TEST DATA:**

Depth #1 \_\_\_\_\_ @ Test MW of \_\_\_\_\_ (ppg)

Depth #2 \_\_\_\_\_ @ Test MW of \_\_\_\_\_ (ppg)

Depth #3 \_\_\_\_\_ @ Test MW of \_\_\_\_\_ (ppg)

LINER #1 \_\_\_\_\_ size, \_\_\_\_\_ ID, \_\_\_\_\_ weight

LINER #2 \_\_\_\_\_ size, \_\_\_\_\_ ID, \_\_\_\_\_ weight

LINER #1 TOP DEPTH \_\_\_\_\_ ft

LINER #2 TOP DEPTH \_\_\_\_\_ ft

LINER #1 SHOE DEPTH \_\_\_\_\_ ft

LINER #2 SHOE DEPTH \_\_\_\_\_ ft


TVD CASING or LINER \_\_\_\_\_ ft

**HOLE DATA:**

TOTAL DEPTH (MD) \_\_\_\_\_ ft

TOTAL DEPTH (TVD) \_\_\_\_\_ ft


BIT DEPTH @ MD / TVD \_\_\_\_\_ / \_\_\_\_\_ ft      BIT SIZE \_\_\_\_\_ inches



DISCLAIMER: This Well Control Worksheet is intended solely for the use of the IADC and IADC accredited schools and organizations engaging in the teaching of the IADC WellCAP Well Control classes. The IADC, its employees or others acting on its behalf, makes no warranties or guarantees expressed, implied or statutory, as to any matter whatsoever, with respect to the use of this Well Control Worksheet.



# GRAPHIC ANALYSIS



## FORMULAS

1. Pressure Gradient (psi/ft) = Mud Weight (ppg) x 0.052
  2. Hydrostatic Pressure (psi) = Mud Weight (ppg) x 0.052 x Depth (ft, TVD)
  3. Capacity (bbls/ft) = Inside Diameter<sup>2</sup> (in.) ÷ 1029.4
  4. Annular Capacity (bbls/ft) = (Inside Diameter of Casing<sup>2</sup> (in.) or Hole Diameter<sup>2</sup> (in.) - Outside Diameter of Pipe<sup>2</sup> (in.)) ÷ 1029.4
  5. Pipe Displacement (bbls/ft) = (Outside Diameter of pipe<sup>2</sup> (in.) - Inside Diameter of pipe<sup>2</sup> (in.)) ÷ 1029.4
  6. Maximum Allowable Mud Weight (ppg) =  $\frac{\text{Surface LOT Pressure (psi)}}{\text{Shoe Depth (ft, TVD)} \times 0.052} + \text{LOT Mud Weight (ppg)}$
  7. MAASP (psi) = [Maximum Allowable Mud Weight (ppg) - Present Mud Weight (ppg)] x 0.052 x Shoe TVD (ft)
  8. Pressure Drop per Foot Tripping Dry Pipe (psi/ft) =  $\frac{\text{Drilling Mud Weight (ppg)} \times 0.052 \times \text{Metal Displacement (bbl/ft)}}{\text{Casing Capacity (bbl/ft)} - \text{Metal Displacement (bbl/ft)}}$
  9. Pressure Drop per Foot Tripping Wet Pipe (psi/ft) =  $\frac{\text{Drilling Mud Weight (ppg)} \times 0.052 \times \text{Closed End Displacement (bbl/ft)}}{\text{Casing Capacity (bbl/ft)} - \text{Closed End Displacement (bbl/ft)}}$
  10. Formation Pressure (psi) = Hydrostatic Pressure Mud in Hole (psi) + SIDPP (psi)
  11. EMW (ppg) @ Shoe = (SICP (psi) ÷ 0.052 ÷ Shoe Depth (ft, TVD)) + Present Mud Weight (ppg)
  12. Sacks (100 lb) of Barite Needed to Weight-Up Mud =  $\frac{\text{Bbls of Mud in System} \times 14.9 \times (\text{KMW} - \text{OMW})}{(35.4 - \text{KMW})}$
- NOTE: This formula assumes that the average density of Barite is 35.4 ppg and the average number of sacks (100lb) per barrel is 14.9.*
13. Volume Increase from Adding Barite (bbls) = Number of Sacks (100 lb) added ÷ 14.9
  14. Equivalent Mud Weight (ppg) @ \_\_\_\_\_ depth (ft) =  $\left[ \frac{\text{Pressure (psi)}}{\text{Depth (ft, TVD)} \times 0.052} \right] + \text{Current Mud Weight (ppg)}$
  15. Estimated New Pump Pressure at New Pump Rate (psi) = Old Pump Pressure (psi) x  $\left[ \frac{\text{New Pump Rate (SPM)}}{\text{Old Pump Rate (SPM)}} \right]^2$
  16. Estimated New Pump Pressure with New Mud Weight (psi) = Old Pump Pressure (psi) x  $\frac{\text{New Mud Weight (ppg)}}{\text{Old Mud Weight (ppg)}}$

DISCLAIMER: This Well Control Worksheet is intended solely for the use of the IADC and IADC accredited schools and organizations engaging in the teaching of the IADC WellCAP Well Control classes. The IADC, its employees or others acting on its behalf, makes no warranties or guarantees expressed, implied or statutory, as to any matter whatsoever, with respect to the use of this Well Control Worksheet.